

FLOW 8 Firmware Update

V11748 - (29 July 2021)

Welcome

Congratulations on purchasing the innovative FLOW 8 compact mixer. This firmware update introduces minor Bugfixes and Improvements.

Behringer is constantly adding new features and making enhancements, so that you always experience the best possible performance. To make use of the latest features and improvements, we recommend installing the latest firmware, driver and app versions, always. The firmware update 11748 for FLOW 8 works with remote app FLOW MIX 1.4 and Windows ASIO/WDM driver version 5.0.

This new FLOW Firmware version contains:

Bugfixes:

- Fix for leveljumps when changing gain on hardware (Hold MAIN)
- Fix for fader offset when switching layer control sets
- Fix multi-fader race condition on Monitor 2 sends, when MON LINK is enabled

Improvements:

- Support for alternative DAC hw

Update Process:

To update FLOW 8 to the latest firmware please use the SimplyPUT update tool. SimplyPUT is available for Mac, Windows and Linux and can be downloaded from the FLOW 8 product page at [behringer.com](https://www.behringer.com).

WINDOWS:

- 1. Please make sure you have installed the latest USB-Driver, which is available on the FLOW 8 product page!**
2. Connect FLOW 8 to your computer using the USB Type B socket
3. Make sure your computer is connected to the internet
4. Launch Application
SimplyPUT will detect FLOW 8 and search for the latest firmware available on the server
SimplyPUT will always preselect the latest version available
5. Select UPDATE
SimplyPUT will start transferring the new firmware to the hardware using the installed USB-Driver
After a successful update, FLOW 8 will indicate the new Firmware-Version and reboot automatically

MAC:

1. Connect FLOW 8 to your computer using the USB Type B socket
2. Make sure your computer is connected to the internet
- 3. To launch application please use rightclick (CTRL+Click) and select Open. Select Open on the upcoming pop up again**

SimplyPUT will detect FLOW 8 and search for the latest firmware available on the server
SimplyPUT will always preselect the latest version available
4. Select OPEN
This will enable the DFU-Mode on the hardware.
Recognisable by a red display on the hardware showing the current installed Firmware-Version.
5. Select UPDATE
Simply Put will start flashing the new firmware to the hardware
After a successful update FLOW 8 will indicate the new Firmware-Version and reboot automatically